

# How to Fit

## Perfect Fit Shutters

---



Using a credit card as a guide, slot a bracket into the corner of each rubber seal on the window.

Once all brackets are in place the shutter is ready to be installed. Line the bracket punches in the bottom of the frame with the bottom brackets.

Once the bottom of the frame is clipped in, push the top side of the frame into the top brackets. Your Perfect Fit Shutter is now installed!

**Shutters requiring side brackets** - offer the shutter up to your window or door and mark the location of the top of the side bracket punches with a pencil on the window frame. The nub of each bracket should be in line with the mark on the window frame.

For the top and bottom brackets, use a credit card as a guide to slot a bracket into the corner of each rubber bead.

Install the Shutter by lining up the bracket punches to the top brackets, clipping these and the side brackets in, before the bottom brackets.