

How to Fit

Perfect Fit Venetian Blinds

To assemble your Perfect Fit® blind, there is a simple assembly procedure to follow before fitting may commence. Carefully unwrap the blind components - **PLEASE DO NOT USE SCISSORS** as you may cut the cords. Unravel all guides and control cords. The blind will have the top and bottom parts of the frame attached together with cord.

Lay out the blind face down on a clean, even surface.



Select the left hand frame component and guide onto the exposed arm of the bottom left corner joint.

Slide the frame along the arm until secure. Repeat the process on the top left hand corner joint. Now follow the same procedure for the right hand side of the frame. Once the frame is complete tighten the securing screws attached to each corner joint. Your Perfect Fit® blind is now ready to be fitted.



FITTING THE FRAME

To ensure all brackets are in the correct position for fitting (85mm from beading) use a credit card in the corner of the window to locate the bracket position.

For ease of insertion, use a lubricant in the form of washing up liquid on the base of each bracket.

Line up the bracket with the base or top of the credit card (depending on which corner of the window you are working) and fit the bracket by pushing it between the glass and the rubber seal of the window.

Repeat for all 4 corners of the window, and intermediate brackets (if required) then clean excess lubricant prior to clipping on the frame. Once the frame is installed, you can clip on the wand.



TENSIONING THE BLIND

We tension all blinds before dispatch, but sometimes they can lose tension during transit or with use over time. To add more tension to your blind, simply remove it from the window and place face down on a hard surface. Carefully untie the knot from one side of the spring at the bottom (the blind will lose all tension), tie a new knot, 1-5mm up, and test. If the blind still requires some more tension, repeat the process.