

How to Measure

Grip Fit Roller Blind

CHECKING YOUR WINDOWS ARE COMPATIBLE WITH GRIP FIT

Is your recess solid?

Because the bracket system pushes out with up to 60kg of force, your recess needs to be solid. We have tested a whole host of substrates including brick, tile, plaster board and wood which are all suitable.

However if your recess will move when pushed for example if you have plasterboard with nothing behind it, then your window won't be suitable for Grip Fit.

Is your recess deep enough?

The cassette is a total of 8cm deep, so your recess must be at least this deep to house the product.

Are your walls parallel?

The Grip Fit Roller blind grips to the side of your recess, As a result of this your walls need to be parallel to each other and not taper forward or back where you are going to install the blind as this would stop the rubber compound from making contact with the wall fully.

HOW TO MEASURE FOR GRIP FIT

It is important to use a steel or top reader tape measure and measure to the nearest mm.

- Measure the depth of your recess. It tends to be at least 8cm deep to accommodate the Grip Fit cassette.
- Check the walls are solid by pushing on them with your hand. If the walls don't move or bend when you push then they are suitable.

- Measure the width of your recess at the top of the window, where you are planning on installing the blind. It is important to measure to the nearest mm.
- Measure the drop of the window in three places and note down the longest drop.

